

## TABLE OF CONTENTS

SECTION	SUBJECT	PAGE
<b>01</b> SERVICE TOOLS AND PRODUCTS	01 - Service Tools	01-01-1
	02 - Service Products	01-02-1
<b>02</b> PERIODIC INSPECTION CHART	00 - PERIODIC INSPECTION CHART	02-00-1
<b>03</b> ENGINE	00 - ENGINE	03-00-1
	01 - Water-Flooded Engine	03-01-1
	02 - Removal and Installation	03-02-1
	03 - Top End	03-03-1
	04 - PTO Flywheel and Magneto	03-04-1
	05 - Bottom End	03-05-1
	06 - Rotary Valve and Reservoir	03-06-1
	07 - Exhaust System	03-07-1
<b>04</b> COOLING SYSTEM	00 - COOLING SYSTEM	04-00-1
	01 - Components	04-01-1
	02 - Circuit	04-02-1
	03 - Flushing and Care	04-03-1
<b>05</b> FUEL SYSTEM	00 - FUEL SYSTEM	05-00-1
	01 - Fuel circuit	05-01-1
	02 - Air Intake	05-02-1
	03 - Carburetors	05-03-1
<b>06</b> OIL SYSTEM	00 - OIL SYSTEM	06-00-1
	01 - Oil Injection Reservoir	06-01-1
	02 - Oil Injection Pump, Repair and Adjustment	06-02-1
<b>07</b> ELECTRICAL	00 - ELECTRICAL	07-00-1
	01 - Wiring Diagram	07-01-1
	02 - Ignition Timing	07-02-1
	03 - Battery	07-03-1
	04 - Electric Starter	07-04-1
	05 - Magneto System	07-05-1
	06 - CDI and Charging Systems	07-06-1
	07 - Spark Plugs	07-07-1
08 - Instruments	07-08-1	
<b>08</b> PROPULSION AND DRIVE SYSTEMS	00 - PROPULSION AND DRIVE SYSTEMS	08-00-1
	01 - Propulsion and Drive Systems	08-01-1
	02 - Reverse System	08-02-1
	03 - Variable Trim System (VTS)	08-03-1
<b>09</b> STEERING SYSTEM	00 - STEERING SYSTEM	09-00-1
	01 - Steering System	09-01-1
<b>10</b> HULL / BODY	00 - HULL / BODY	10-00-1
	01 - Hull / Body	10-01-1
	02 - Inflatable Tube	10-02-1
<b>11</b> STORAGE	00 - STORAGE	11-00-1
<b>12</b> TECHNICAL DATA	00 - TECHNICAL DATA	12-00-1
	01 - SP 5806, SPI 5808 and SPX 5807 Models	12-01-1
	02 - GTS 5813 and GTX 5861 Models	12-02-1
	03 - XP 5852 Model	12-03-1
	04 - EXPLORER 5820 Model	12-04-1
<b>13</b> TROUBLESHOOTING	00 - TROUBLESHOOTING	13-00-1