

---

# TABLE OF CONTENTS

---

SECTION	SUBSECTION	PAGE
SAFETY NOTICE .....		III
WHAT'S NEW .....		IV
INTRODUCTION .....		V
<b>01</b>	<b>SERVICE TOOLS AND SERVICE PRODUCTS</b>	
	01 – Service tools.....	01-01-1
	02 – Service products.....	01-02-1
<b>02</b>	<b>LUBRICATION AND MAINTENANCE</b>	
	01 – Lubrication and maintenance chart .....	02-01-1
<b>03</b>	<b>TROUBLESHOOTING</b>	
	01 – Table of contents.....	03-01-1
	02 – Engine .....	03-02-1
	03 – Fuel and oil systems.....	03-03-1
	04 – Transmission and brake systems .....	03-04-1
	05 – Electrical system .....	03-05-1
	06 – Suspension and track .....	03-06-1
<b>04</b>	<b>ENGINE</b>	
	01 – Table of contents.....	04-01-1
	02 – 377, 443 and 503 engine types .....	04-02-1
	03 – 593 engine type .....	04-03-1
	04 – Leak test and engine dimension measurement .....	04-04-1
	05 – CDI system.....	04-05-1
	06 – Oil injection system.....	04-06-1
	07 – Axial fan cooling system.....	04-07-1
	08 – Liquid cooling system.....	04-08-1
	09 – Rewind starter.....	04-09-1
	10 – Carburetor and fuel pump .....	04-10-1
	11 – Fuel tank and throttle cable .....	04-11-1
<b>05</b>	<b>TRANSMISSION</b>	
	01 – Table of contents.....	05-01-1
	02 – Drive belt .....	05-02-1
	03 – Drive pulley.....	05-03-1
	04 – Driven pulley.....	05-04-1
	05 – Pulley distance and alignment.....	05-05-1
	06 – Brake .....	05-06-1
	07 – Chaincase .....	05-07-1
	08 – Gearbox .....	05-08-1
	09 – Drive chain.....	05-09-1
<b>06</b>	<b>ELECTRICAL</b>	
	01 – Table of contents.....	06-01-1
	02 – Ignition timing.....	06-02-1
	03 – Spark plugs.....	06-03-1
	04 – Battery.....	06-04-1
	05 – Electric starter .....	06-05-1
	06 – Testing procedure .....	06-06-1

---